

DaierTek 360 Adjustable Starlink Mini Wall Mount



1
Apply the adhesive sealant to the location where you want to install the bracket base.



2
Secure the bracket base to the sealant using screws.



3
Align the side wall of the pipe with the circular hole groove and insert it onto the screws on the pipe adapter. Tighten the screws.



4
Feed the DC Power Cable through the conduit and attach the conduit adapter to the Starlink Mini.



5
Adjust the Starlink Mini's signal reception direction, then connect the pipe to the base and tighten the knob.



6
Thread the DC Power Cable through the holes, close the base cover plate, and secure the DC Power Cable with cable clips as needed.

How to Remove the Base Cover Plate



The cover plate is hooked onto the base.



Use a flathead screwdriver-like tool
to pry the hook in the direction of the arrow
to remove the base cover plate
(removal tool not included with the product).